



# Nokia Lumia 620 Screen Replacement

Replace digitizer and/or lcd

Written By: ivan coene



## INTRODUCTION

Don't forget to turn off the phone first.

When you disconnect the digitizer there is a rev number

it only works with the same rev



for example rev 1.3



### TOOLS:

- [T5 Torx Screwdriver](#) (1)
  - [iFixit Opening Picks set of 6](#) (1)
  - [iFixit Opening Tools](#) (1)
-

## Step 1 — Screen



- Open cover
- Take out battery
- Take out the sim card-tray


## Step 2 — Screws



- 4 x t5 screws
- 2x t5 screws (slightly shorter than the top and bottom screws).



## Step 3 — Connectors



- Disconnect connectors

- Digitizer



- LCD

## Step 4 — Main board





- Remove main board

## Step 5 — Frame



- Open the 6 clips

## Step 6 — Speaker and front-camera



- Remove
  - Speaker
  - Front camera





## Step 7 — Lcd



- Remove Lcd from digitizer

## Step 8 — Done



- You are ready

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 06:52:10 PM.

